


D Montageanleitung
I Istruzioni di montaggio
NL Montage - instructie


GB Assembling instructions
F Instructions de montage
E Instrucciones para el montaje

PL Instrukcja montażu
RUS Инструкция по монтажу
CZ Montážní návod


ZM-8PN1 L/R - ZO-8PN1 L/R




ZM-8PN2 - ZO-8PN2





ZM-8PNX L/R - ZO-8PNX L/R




ZM-8PW1 L/R + Z-8W L/R - ZO-8PW1 L/R + Z-8W L/R




i







ZM-8PN1 L/R -
ZO-8PN1 L/RZM-8PN2 -
ZO-8PN2ZM-8PNX L/R -
ZO-8PNX L/RZM-8PW 1 L/R
ZO-8PW 1 L/R






1



2









i

ZM-8PW 1 L/R + Z-8W L/R -
ZO-8PW 1 L/R + Z-8W L/R

1.




2.




3.

Ø 6 mm




4.

Ø 6 mm




5.

SRAKVA3938




6.


SRAM46KFS




12




1.




2.



3.




4.




i


ZM-8PN1 L/R -
ZO-8PN1 L/R




ZM-8PN2 -
ZO-8PN2



ZM-8PNX L/R -
ZO-8PNX L/R



ZM-8PW 1 L/R + Z-8W L/R -
ZO-8PW 1 L/R + Z-8W L/R



13

